


Personal Audio System

Operating Instructions



http://www.sony.net/

Europe Only



Disposal of waste batteries (applicable in the European Union and other European countries with separate collection systems)
 This symbol on the battery or on the packaging indicates that the battery provided with this product shall not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. The chemical symbols for mercury (Hg) or lead (Pb) are added if the battery contains more than 0.0005% mercury or 0.004% lead. By ensuring these batteries are disposed of correctly, you will help prevent potentially negative consequences for the environment and human health which could otherwise be caused by inappropriate waste handling of the battery. The recycling of the materials will help to conserve natural resources.

In case of products that for safety, performance or data integrity reasons require a permanent connection with an incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery will be treated properly, hand over the product at end-of-life to the applicable collection point for the recycling of electrical and electronic equipment.

For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery over to the applicable collection point for the recycling of waste batteries.

For more detailed information about recycling of this product or battery, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.

Licence and Trademark Notice

- MPEG Layer-3 audio coding technology and patents licensed from Fraunhofer IIS and Thomson.
- Windows Media is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
- This product contains technology subject to certain intellectual property rights of Microsoft. Use or distribution of this technology outside of this product is prohibited without the appropriate license(s) from Microsoft.
- The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.
- The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.
- Android is a trademark of Google Inc.
- Other trademarks and trade names are those of their respective owners. In this manual, ™ and ® marks are not specified.

WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

To reduce the risk of fire or electric shock, do not expose this apparatus to dripping or splashing, and do not place objects filled with liquids, such as vases, on the apparatus.

As the main plug is used to disconnect the unit from the mains, connect the unit to an easily accessible AC outlet. Should you notice an abnormality in the unit, disconnect the main plug from the AC outlet immediately.

The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.


Excessive sound pressure from earphones and headphones can cause hearing loss.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

The nameplate is located on the bottom exterior.

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives


This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Inquiries related to product compliance based on European Union legislation shall be addressed to the authorized representative, Sony Belgium, bijkantoort van Sony Europe Limited, Da Vincilaan 7-D1, 1935 Zaventem, Belgium. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.



Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)
 This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.

Power Sources

Connect the AC power cord **A**, or insert six R14 (size C) batteries (not supplied) into the battery compartment **B**.




- Replace the batteries when the OPR/BATT indicator **BT** dims, or when the unit becomes inoperable. Replace all of the batteries with new ones. Before you replace the batteries, be sure to remove any AC and disconnect any USB devices or optional components from the unit.
- To use the unit on batteries, disconnect the AC power cord from the unit and the wall outlet.

To use the power-management function

This unit is equipped with an automatic standby function. With this function, the unit enters standby mode automatically after about 15 minutes if there is no operation or audio signal output. To turn standby mode on or off, press DISPLAY **BT** while holding down **BT**. Each time you press the buttons, "AUTO STANDBY ON" or "AUTO STANDBY OFF" appears on the display.

- The displayed content starts flashing on the display about 2 minutes before entering standby mode.
- In standby mode with the AC power cord connected, "STANDBY" appears on the display.
- The automatic standby function is not available with the FM function.



* **BT** and VOLUME **+** **BT** have a tactile dot.

Illumination
 The illumination **BT** has the following two features.

Indication of function change
 When switching to one of five functions, the center of the illumination (white) increases in intensity to notify the user of a function change. When switching to the Bluetooth function, both sides of the illumination are also lit in blue.

Before using the unit

To turn the power on or off
 Press OPERATE **BT**. You can also turn on the power of this unit using the direct power-on function (below).
 In this manual, operations are mainly explained using the direct power-on function.

To use the direct power-on function
 Press CD **BT**, USB **BT**, BLUETOOTH **BT**, RADIO DAB/FM **BT**, or AUDIO IN **BT** while the unit is turned off. The power turns on with the relevant function selected.

To adjust the volume
 Press VOLUME **+** or **-** **BT**. The volume level of this unit that contains MP3/WMA files is skipped.

To listen through headphones
 Connect headphones to the **BT** (headphones) jack **BT**.

To reinforce the bass
 Press MEGA BASS **BT**. "MEGA BASS" lights up on the display. To return to normal sound, press the button again.

To turn off the light sync function
 The light sync function creates lighting effects that synchronize with the music source. By default, this function is on, but you can turn it off as desired.

Hold down LIGHT SYNC **BT** until "LIGHT SYNC OFF" appears on the display.
 To turn on the function, hold down the button again until "LIGHT SYNC ON" appears.

Playing a music disc

You can play the following types of discs with this unit.


- Audio CDs on which CD-DA tracks are recorded in CD-DA disc format
- CD-R/CD-RW discs on which MP3 or WMA audio files are recorded in ISO 9660 Level 1/Level 2 or Joliet

1 Press CD **BT** to turn on the CD function.




2 Press PUSH OPEN/CLOSE **BT**, and place a disc in the CD compartment with the label side up.

When placing the disc, gently push the center part of the disc until a click sound is heard and the disc snaps in the hole of the disc holder.



3 Close the CD compartment door securely by pushing down at the PUSH OPEN/CLOSE **BT** mark **BT**. (Example: when an audio CD is loaded)



* If MP3/WMA files are present only on the root directory "ROOT" folder, "FLDR" appears on the display.

4 Press **BT** to start playback.



When you play an MP3/WMA disc, the folder name¹ and song title are displayed before the playing time² appears.
¹If there is no folder, "ROOT" appears on the display.
²If the playing time is longer than 100 minutes, "----" appears on the display.

Other operations


To	Do this
Pause playback	Press BT . To return to playback, press the button again.
Stop playback	Press BT . When you press BT after playback is stopped, playback starts from the beginning of the track/file you were last playing (Resume Play).
Cancel Resume Play	Press BT twice. When you press BT after you cancel Resume Play, playback starts from the beginning of the first track/file.
Select a folder on an MP3/WMA disc	Press BT (Folder) + or - BT .
Select a track/file	Press BT (Folder) + or - BT . You can skip tracks/files one by one.
Find a point in a track/file	Hold down BT or BT during playback, and release the button at the desired point. When locating a point while paused, press BT to start playback after the desired point is found.

Tip
 Resume Play is cancelled if you press **BT**, open the CD compartment or turn off the unit.

Lighting effects for audio output
 Lighting effects (both sides of the illumination are lit in red) are created that synchronize with the music source. You can turn this function on or off as desired (See "To turn off the light sync function").

Example of folder structure and playing order

The playing order of the folders and files is as follows:



Notes on MP3/WMA discs

- When a disc is loaded, the unit reads all the files on that disc. During this time, "READING" is displayed. If there are many folders or non-MP3/WMA files on the disc, it may take a long time for play to begin or for the next MP3/WMA file to start to play.
- We recommend that non-MP3/WMA files or unnecessary folders are excluded when creating MP3/WMA discs.
- During playback, folders that contain no MP3/WMA files are skipped.
- The audio formats supported by this unit are as follows:
 - MP3: File extension ".mp3"
 - WMA: File extension ".wma"
 Note that even if the file name has the correct file extension but the actual file was created in a different audio format, this unit may produce noise or may malfunction.
- MP3 PRO format is not supported.
- WMA files encoded in WMA DRM, WMA Lossless and WMA PRO formats cannot be played back.
- This unit cannot play audio files in a disc in the following cases:
 - When the total number of audio files exceeds 511.
 - When the total number of folders on a single disc exceeds 311.
 - When the directory level (folder depths) exceeds 9 (including the "ROOT" folder).
- Folder names and file names can be displayed with up to 32 characters, including quotation marks.
- Characters and symbols that cannot be displayed by the unit will appear as "-".
- This unit conforms to version 1.0, 1.1, 2.2, 2.3 and 2.4 of the ID3 tag format for MP3 files and the WMA tag format (defined by ASF (Advanced Systems Format) specification) for WMA files. When a file has the ID3 or WMA tag information, song title, artist name, and album name will be displayed. If a file does not have the tag information, the unit displays as follows:
 - File name instead of the song title.
 - "NO ARTIST" message instead of the artist name.
 - "NO ALBUM" message instead of the album name.
 ID3 and WMA tag information can be displayed up to 32 characters.

To change play modes

Press MODE **BT** repeatedly while the disc is stopped. For details, see "Selecting play mode" on the back page.

Listening to music on a USB device

You can listen to audio files stored on a USB device (a digital music player or USB storage media). Audio files in MP3 and WMA formats* can be played on this unit. For compatible USB devices, see "Compatible USB devices" on the back page.


- Files with DRM (Digital Rights Management) copyright protection or files downloaded from an online music store cannot be played on this unit. If you try to play one of these files, the unit plays the next unprotected audio file.

1 Connect the USB device to the **BT** (USB) port **BT**.

Note
 This unit cannot be used to charge USB devices.

2 Press USB **BT** to turn on the USB function. The volume label¹ scrolls once, then the total folder number appears on the display.

3 Press **BT** to start playback. The folder name and song title are displayed, and then the file number and playing time appear.



* If the playing time is longer than 100 minutes, "----" appears on the display.

Other operations

To	Do this
Stop recording	Press BT . An MP3/WMA file is created up to the point the recording was stopped.
Remove a USB device	Press USB BT , then hold down BT until "NO DEV" appears on the display, and then disconnect the USB device.

Other operations

To	Do this
Pause playback	Press BT . To return to playback, press the button again.
Stop playback	Press BT . When you press BT after playback is stopped, playback starts from the point where you stopped playback (Resume Play).
Cancel Resume Play	Press BT twice. When you press BT after you cancel Resume Play, playback starts from the beginning of the first track/file.
Select a folder	Press BT (Folder) + or - BT .
Select a file	Press BT (Folder) + or - BT . You can skip files one by one. To skip files continuously, hold down BT or BT and release the button at the desired track/file.
Find a point in a file	Hold down BT or BT during playback, and release the button at the desired point. When locating a point while paused, press BT to start playback after the desired point is found.
Remove a USB device	Hold down BT until "NO DEV" appears on the display, and then disconnect the USB device.

* When playing a VBR MP3/WMA file, playback may restart from a different point.

Note
 When removing a USB device, always hold down **BT** until "NO DEV" appears on the display. Removing the USB device without performing this step may corrupt the data on the USB device or damage the device itself.

To change play modes
 Press MODE **BT** repeatedly while the USB device is stopped. For details, see "Selecting play mode" on the back page.

- It may take a long time before playback starts when:
 - The folder structure is complex.
 - The USB device is close to capacity.
- Do not save non-MP3/WMA files or unnecessary folders to a USB device that contains MP3/WMA files.
- During playback, folders that contain no MP3/WMA files are skipped.
- The audio formats supported by this unit are as follows:
 - MP3: File extension ".mp3"
 - WMA: File extension ".wma"
 Note that even if the file name has the correct file extension but the actual file was created in a different audio format, this unit may produce noise or may malfunction.
- MP3 PRO format is not supported.
- WMA files encoded in WMA DRM, WMA Lossless and WMA PRO formats cannot be played back.
- This unit cannot play audio files on a USB device in the following cases:
 - When the total number of audio files in a single folder exceeds 999.
 - When the total number of audio files on a single USB device exceeds 5,000.
 - When the total number of folders on a single USB device exceeds 255 (including the "ROOT" folder).
 - When the directory level (folder depths) exceeds 8 (including the "ROOT" folder).
 These numbers may vary depending on the file and folder structure.
- Compatibility with all encoding/writing software is not guaranteed. If audio files on the USB device were originally encoded with incompatible software, those files may produce noise or interrupted sound, or may not be played back at all.

Recording music from a disc to a USB device

You can record a whole disc (Synchro Recording) or a currently playing track or file (single track recording) to a USB device (digital music player or USB storage media, etc.).
 When recording from a CD, the tracks are recorded as MP3 files at 128 kbps. When recording from an MP3/WMA disc, MP3/WMA files are recorded with the same bit rate as the original MP3/WMA files. For compatible USB devices, see "Compatible USB devices" on the back page.

Recording music from a disc to a USB device

- Connect the USB device to the **BT** (USB) port **BT**.
- Place a disc you want to record in the CD compartment.

To record a whole disc
 Proceed to step 3.

To record MP3/WMA files in a specific folder
 Press **BT** (Folder) + or - **BT** repeatedly to select the folder you want.

To record only your favorite tracks/files
 Perform steps 1 to 5 of "Creating your own program (Program Play)" on the back page.

To record a single track/file
 Select and start playback of the track/file you want to record.

3 Press REC CD **BT**. "REC" flashes and the unit starts calculating the amount of free space on the USB device.



When the calculation is finished, "FREE**"/"FREE***" (remaining storage space on the device, in gigabytes/megabytes), and then "PUSH ENT" appears on the display. If "LOW ***M" appears on the display, there is insufficient space on the device. To cancel recording, press **BT**. To continue recording anyway, proceed to step 4.

4 Press ENTER **BT**.

Recording starts. Do not remove the USB device while recording. Playback stops automatically when Synchro Recording is completed. Playback continues when recording of a single track/file is completed.

Other operations

To	Do this
Stop recording	Press BT . An MP3/WMA file is created up to the point the recording was stopped.
Remove a USB device	Press USB BT , then hold down BT until "NO DEV" appears on the display, and then disconnect the USB device.

To erase audio files or folders from the USB device

- Select the audio file or folder you want to erase. Press **BT** or **BT** to select an audio file. Press **BT** (Folder) + or - **BT** to select a folder.
- Press ERASE **BT**. "ERASE" appears on the display.
- Press ENTER **BT**. "TRACK ERASE" or "FOLDER ERASE" appears on the display.
- Press ENTER **BT**. The selected audio file or folder is erased, and "COMPLETE" appears on the display.

Folder and file generation rules
 When first recording to a USB device, a "MUSIC" folder is created directly below the "ROOT". Folders and files are generated within any of the transfer mode-oriented folders as follows.

Synchro Recording¹

Recording source	Folder name	File name
MP3/WMA	Same as the recording source ²	
CD-DA	"FLDR001"~"3"	"TRACK001"~"4"

Single track recording

Recording source	Folder name	File name
MP3/WMA	"RECT"~5	Same as the recording source ²
CD-DA		"TRACK001"~"4"

- ¹Recording a whole disc, MP3/WMA files in a specific folder and only your favorite tracks/files (Program Play)
- ²A folder name of up to 32 characters can be assigned.
- ³Folder names are assigned in sequential order up to a maximum of 255 (including the "ROOT" and "MUSIC" folders).
- ⁴File names are assigned in sequential order.
- ⁵A new name is recorded to the "RECT" folder each time single track recording is performed.

- Notes**
- If you start recording in shuffle play or repeat play mode, the selected play mode is automatically changed to normal play.
 - Do not remove the USB device during recording or erase operations. Doing so may corrupt the data on the device or damage the device itself.
 - While recording from an MP3/WMA disc, no sound is output and "HI-SPEED" appears on the display.
 - CD-TEXT information is not transferred in the created MP3 files.
 - Recording stops automatically if:
 - The USB device runs out of space during recording.
 - The number of audio files and folders on the USB device reaches the limit that the unit can manage.
 - The function is changed.
 - If a folder or file that you are trying to record has the same name as folder or file already existing on the USB device, a sequential number is added after the name without overwriting the original folder or file.
 - You cannot erase MP3/WMA folders during playback or pause.
 - Non-MP3/WMA format files or sub folders in the folder to be erased are not erased.
 - Radio source cannot be recorded to a USB device.

Making a wireless connection with Bluetooth devices

You can enjoy music wirelessly via the Bluetooth function built in to your devices. Choose one of the following three connection methods best suited for the Bluetooth device. For details on how to operate your device, refer to the operating instructions supplied with the device.

Pairing with a Bluetooth device: see **Pattern A**
 Bluetooth devices need to be "paired" with each other beforehand.

Connecting with a paired device: see **Pattern B**
 To listen to music with a Bluetooth device that has been paired, see this pattern.

One touch connection with a smartphone (NFC): see **Pattern C**
 Using an NFC-compatible smartphone, you can establish a Bluetooth connection by just touching the unit with it.

Check the following before operating the unit.

- Both the unit and the device are placed within 1 m of each other.
- The unit enters pairing mode, and the OPR/BATT indicator **BT** is lit.
- The operating instructions supplied with the device are at hand.

Pattern A
Pairing and connecting with a Bluetooth device

1 Press BLUETOOTH **BT** to turn on the Bluetooth function.



2 Turn on the Bluetooth function of the Bluetooth device. For details, refer to the operating instructions supplied with the device.

If no devices have been paired, such as when you press BLUETOOTH **BT** for the first time after turning on the unit, the unit automatically enters pairing mode, and the Bluetooth indicator **BT** and "PAIRING" on the display flash. In this case, proceed to step 4.

3 Hold down BLUETOOTH-PAIRING **BT** until two beeps are heard.
 The unit enters pairing mode, and the Bluetooth indicator **BT** and "PAIRING" on the display flash.


4 Perform the pairing procedure on the Bluetooth device to detect the unit.

5 Select "SONY-ZS-R570BT/BTB" shown on the display of the Bluetooth device. If "SONY-ZS-R570BT/BTB" does not appear on the device's display, repeat from step 2.

Note
 Some devices cannot display a list of detected devices.

6 If Passcode¹ input is required on the display of the Bluetooth device, input "0000".
 The Bluetooth connection is established. "BT AUDIO" appears on the display.

* "Passcode" may be referred to as "Passkey," "PIN code," "PIN number," or "Password."



Tip
 To pair with other Bluetooth devices, repeat steps 2 to 6 for each device.

- Notes**
- Pairing mode of the unit is cancelled after about 5 minutes, and the Bluetooth indicator **BT** flashes. If pairing mode is cancelled while performing this procedure, start over from step 3.
 - The passcode of the unit is fixed as "0000". The unit cannot be paired with a Bluetooth device whose Passcode is not "0000".
 - Once Bluetooth devices are paired, there is no need to pair those devices again. However, in the following case, you will need to perform the pairing procedure again.
 - The unit is paired with 10 or more devices. The unit can be paired with up to 9 Bluetooth devices. If a new device is paired after 9 devices have been paired, the device whose latest connection time is the oldest among the 9 paired devices is replaced with the new one.
 - More than one device can be paired with the unit, but sound will be heard from just one of these devices.

Pattern B Connecting with a paired Bluetooth device

1 Press BLUETOOTH **BT** to turn on the Bluetooth function.




2 Turn on the Bluetooth function of the Bluetooth device.

Tip
 In the case of the last-connected Bluetooth device, the unit tries to re-establish a Bluetooth connection with it if the device's Bluetooth function is on. When a Bluetooth connection is established, the Bluetooth indicator **BT** on the display stays on.

3 Select "SONY-ZS-R570BT/BTB" shown on the display of the Bluetooth device. If necessary, select Bluetooth profile "A2DP," which the unit supports. For details on the profile, see "What is Bluetooth Wireless Technology?"

The Bluetooth connection is established and "BT AUDIO" appears on the display.

Other Operations



*►H [18] and VOLUME + [7] have a tactile dot.

Using the display

Checking MP3/WMA file information

Press DISPLAY [16] repeatedly while playing an MP3/WMA file on the disc/USB device.




The display changes as follows:

- Song title [J]¹
 - Artist name [K]¹
 - Album name [O]¹
 - Current file number and playing time²
- ¹If the file does not have corresponding ID3 or WMA tag information, the file name, "NO ARTIST," and "NO ALBUM" scroll instead of the song title, artist name, and album name, respectively.
- ²The artist name or album name will change to this in a few seconds.

Checking the free space on the USB device

1 Press MODE [17] repeatedly to cancel folder play mode, folder repeat play mode, program play mode or program repeat play mode.



2 Press DISPLAY [16] while the USB device is stopped.



*FREE**G*/FREE**M* (remaining storage space on the device, in gigabytes/megabytes) appears on the display.


Checking the connected Bluetooth device name

Press DISPLAY [16] while connecting the Bluetooth device.



Checking the radio information

Press DISPLAY [16] repeatedly while listening to the radio.



The display changes as follows:

When listening to FM
Preset number¹ → Station name² → PTY label³ (see "PTY (programme type)" in "Specifications") → Radio text⁴ → Frequency

When listening to DAB
Preset number¹ → DLS (Dynamic Label Segment)² → PTY label³ (see "PTY (programme type)" in "Specifications") → Ensemble label⁴ → Channel → Bit rate⁵ → Signal level⁶ → Component label

When listening to RDS
Introduced by the European Broadcasting Union (EBU) in 1987, the Radio Data System (RDS) allows information such as station names to be received via the 57 kHz sub-carrier signal of FM broadcasts. However, the availability of RDS data varies depending on the area. It therefore may not always be possible to receive RDS information.

Using the RDS functions
The unit supports the following RDS functions.

RDS function	Description
Station name	Displays the station name you are listening to
PTY (programme type)	Displays the programme type of the received programme.
RT (radio text)	Displays free-form textual information.

Notes

- The RDS functions will not be activated if the FM station being received is not transmitting RDS data. They may also not work properly in areas where RDS transmissions are in the experimental stage.
- If the radio signal being received is weak, it may take time to receive the RDS data.

Selecting play mode

You can set the unit to play tracks or files repeatedly or in random order while a disc/USB device is stopped.



Each time you press the button, the indication changes as follows:

- Normal play (None)
 - Single repeat (◁ 1)
 - All repeat (◁ 2)
 - Selected folder play (◁ 3)
 - Selected folder repeat play (◁ 4)
 - Shuffle play (SHUF)
 - Program play (PGM)
 - Program repeat play (◁ 5)
- * These functions are available only when playing MP3/WMA files on an MP3/WMA disc or USB device.

Playing tracks/files repeatedly (Repeat Play)

You can set the unit to repeatedly play CD-DA tracks on an audio CD, or MP3/WMA files on a CD-R/CD-RW disc or on a USB device in normal and program play modes.

1 Press CD [2] or USB [2] to turn on the CD or USB function.

2 Proceed as follows.

To repeat

Do this	Do this
A single track/file	1 Press MODE [17] repeatedly until "1" appears.
2 Press ◁ or ▷ [11] to select a track/file that you want to repeat. When you want to specify a folder that contains MP3/WMA files, press [Folder] + or - [4] first to select a folder, and then press ◁ or ▷ [11] to select a file.	
3 Press ► [13] to start Repeat Play.	

All tracks/files

1 Press MODE [17] repeatedly until "1" appears.
2 Press ► [13] to start Repeat Play.

A selected folder on an MP3/WMA disc or USB device

1 Press MODE [17] repeatedly until [Folder] and "1" appear.
2 Select a folder by pressing [Folder] + or - [4].
3 Press ► [13] to start Repeat Play.

Programmed tracks/files

1 Program tracks/files (see "Creating your own program (Program Play)").
2 Press MODE [17] until "PGM" and "1" appear on the display.
3 Press ► [13] to start Repeat Play.

To cancel Repeat Play
Press [13] to stop playback, and then press MODE [17] repeatedly until "1" (or "1") disappears from the display.

Playing tracks/files in random order (Shuffle Play)
You can set the unit to play CD-DA tracks on an audio CD or MP3/WMA files on a CD-R/CD-RW disc or on a USB device in random order.

1 Press CD [2] or USB [2] to turn on the CD or USB function.

2 Press MODE [17] repeatedly until "SHUF" appears on the display.

3 Press ► [13] to start Shuffle Play.

To cancel Shuffle Play
Press [13] to stop playback, and then press MODE [17] repeatedly until "SHUF" disappears from the display.

Notes

- During Shuffle Play, you cannot select the previous track/file by pressing ◁ [11].
- Resume Play is available when using Shuffle Play mode in the USB function. Press ► [13] after you have stopped Shuffle Play by pressing [13]. Shuffle Play starts from the point where you stopped.

Creating your own program (Program Play)
You can arrange the playing order of up to 25 tracks/files on a disc/USB device.

1 Press CD [2] or USB [2] to turn on the CD or USB function.

2 Press MODE [17] repeatedly until "PGM" appears on the display.

3 Press ◁ or ▷ [11] to select a track/file.

4 Press ENTER [3].

5 Repeat steps 3 and 4 to program additional tracks/files.

6 Press ► [13] to start Program Play.

The created program remains available until you open the CD compartment, remove the USB device or turn off the power of the unit. To play the same program again, press ► [13].

* These functions are available only when playing MP3/WMA files on an MP3/WMA disc or USB device.

Note
If you try to program 26 tracks/files or more, "FULL" appears on the display.

Tip
Resume Play is available when using Program Play mode in the USB function. Press ► [13] after you have stopped Program Play by pressing [13]. Program Play starts from the point where you stopped.

To display programmed track/file information
After creating your own program, you can check information about programmed tracks/files. Press DISPLAY [16] repeatedly and the display changes as follows:

Total programmed step number ↔ Last programmed track/file number and the total playing time*

* "----" appears for MP3/WMA discs and USB devices.

To cancel Program Play
Press [13] to stop playback, and then press MODE [17] repeatedly until "PGM" disappears from the display.

To delete all tracks/files in the current program
Stop playback, and then press [13]. "NO STEP" appears and you can create a new program, following the procedure "Creating your own program (Program Play)".

Presetting radio stations

You can store radio stations in the unit's memory. You can preset up to 30 radio stations, 20 for FM and 10 for DAB.

Presetting FM stations automatically

1 Press RADIO DAB/FM [2] repeatedly to select "FM."

2 Hold down RADIO DAB/FM-SCAN [2] until "AUTO" flashes on the display.

3 Press ENTER [3] to store the station. The stations are stored in memory from lower frequencies to higher ones.

Compatible Bluetooth devices
Compatibility requirements for the devices are as follows. Before using a device with this unit, check that it meets the requirements.

Devices must conform to Bluetooth Standard version 3.0.

Devices must support A2DP (Advanced Audio Distribution Profile) and AVRCP (Audio/Video Remote Control Profile).

NFC capability (required only when using the NFC pairing function of the unit).

For the latest information on compatible Bluetooth devices, including NFC-compatible smartphones, check the websites below.

<http://support.sony-europe.com/>

What is Bluetooth wireless technology?
Bluetooth wireless technology is a short-range wireless technology that enables wireless data communication between digital devices, such as a computer and digital camera. Bluetooth wireless technology operates within a range of about 10 m.

Connecting two devices as necessary is common, but some devices can be connected to multiple devices at the same time.

You do not need to use a cable for connection, nor is it necessary for the devices to face one another, such as the case with infrared technology. For example, you can use such a device in a bag or pocket.

Bluetooth standard is an international standard supported by thousands of companies all over the world, and employed by various companies worldwide.

Communication system and compatible Bluetooth profiles of the unit
Profile is standardization of the function for each Bluetooth device specification. This unit supports the following Bluetooth version and profiles: Communication System: Bluetooth Specification version 3.0

Compatible Bluetooth profiles:
—A2DP (Advanced Audio Distribution Profile): Transmitting or receiving audio content of high quality.
—AVRCP (Audio Video Remote Control Profile): Controlling A/V equipment; pausing, stopping, or starting playback, etc.

Maximum communication range
Use Bluetooth devices within 10 m (line of sight) of the unit.

Maximum communication range may shorten under the following conditions:

- There is an obstacle such as a person, metal, or wall between the unit and Bluetooth device.
- A wireless LAN device is in use near the unit.
- A microwave oven is in use near the unit.
- A device that generates electromagnetic radiation is in use near the unit.
- The unit is placed on a shelf made of steel.

Connecting optional components
You can enjoy the sound from an optional component, such as a portable digital music player, through the speakers of this unit. Be sure to turn off the power of each component before making any connections.

For details, refer to the instruction manual of the component to be connected.

To AUDIO IN jack
To component (e.g. portable digital music player)

To component (e.g. portable digital music player)
Audio connection cable (not supplied)

1 Connect the AUDIO IN jack [14] to the line output jack of the portable digital music player or other component using an audio connection cable (not supplied).

2 Turn the connected component on.

3 Press AUDIO IN [2] and start playing sound on the connected component.

Notes

- If connected to the monoaural output jack of a digital music player, sound may not be emitted through the right speaker of the unit.
- If connected to the line out jack of a digital music player, distortion may occur. If the sound is distorted, connect to the headphones jack instead.
- If connected to the headphones jack of a digital music player, increase the volume of the digital music player, and then adjust the volume of the unit.

Additional Information

Compatible devices

Compatible USB devices
Compatibility requirements for the USB devices are as follows. Before using a device with this unit, check that it meets the requirements.

• Compliance with USB 2.0 (Full Speed)

- Supports Mass Storage mode

* Mass Storage mode is a mode that allows a USB device to become accessible to a host device, enabling file transfers. Most USB devices support Mass Storage mode.

To select a memory on the device for playback or recording
If the USB device has more than one memory (for example, an internal memory and a memory card), you can select which memory to use and then start playback or recording. Make sure to select a memory before starting playback or recording as you cannot select a memory during operation.

1 Connect the USB device to the ◁ (USB) port [12].

2 Press USB [2] to turn on the USB function.

3 Press USB-MEMORY SELECT [2] until "SELECT?" appears on the display.

4 Press ENTER [3].

5 Press ◀ or ▶ [11] repeatedly to select a memory number.

The memory name appears. The name will be displayed in various ways, depending on the specifications of the USB device.

If only one memory can be selected, proceed to step 6.

6 Press ENTER [3].

Notes on the USB device

- Operation is not always guaranteed, even if the USB devices meet the compatibility requirements.
- When a USB device is connected, the unit reads all the files on the device. If there are many folders or files on the device, it may take a long time for the unit to finish reading them.
- Do not connect a USB device to the unit through a USB hub.
- With some connected USB devices, after an operation is performed, there may be a delay before it is performed by this unit.
- This unit may not support all the functions provided with a connected USB device.
- The playback order on this unit may differ from the playback order on a connected USB device.
- This unit cannot be used to charge USB devices.

Compatible Bluetooth devices
Compatibility requirements for the devices are as follows. Before using a device with this unit, check that it meets the requirements.

Devices must conform to Bluetooth Standard version 3.0.

Devices must support A2DP (Advanced Audio Distribution Profile) and AVRCP (Audio/Video Remote Control Profile).

NFC capability (required only when using the NFC pairing function of the unit).

For the latest information on compatible Bluetooth devices, including NFC-compatible smartphones, check the websites below.

<http://support.sony-europe.com/>

Precautions

Discs that this unit CAN play

- Audio CD (CD-DA)* tracks
- CD-R/CD-RW that contains MP3/WMA files and is finalized** correctly.

* CD-DA is the abbreviation for Compact Disc Digital Audio. It is a recording standard used for audio CDs.

**Finalizing is the process to make the CD-R/CD-RW discs playable on the consumer disc player products, and the finalizing can be enabled or disabled as optional settings during disc creation in most recording software.

Discs that this unit CANNOT play

- CD-R/CD-RW other than those recorded in audio CD format or formats conforming to ISO 9660 Level 1/Level 2 or Joliet
- CD-R/CD-RW with poor recording quality, CD-R/CD-RW with scratches or that is dirty, or CD-R/CD-RW recorded using an incompatible recording device
- CD-R/CD-RW that is unfinalized or finalized incorrectly

Notes on discs

- Before playing, clean the CD with a cleaning cloth. Wipe the CD from the center out. If there are scratches, dirt or fingerprints on the CD, a tracking error may occur.
- Do not use solvents such as benzine, thinner, commercial available cleaners or anti-static spray intended for vinyl LPs.
- Do not expose the CD to direct sunlight or heat sources such as hot air drier, or leave it in a car parked in direct sunlight as there can be a considerable rise in temperature inside the car.
- Do not stick paper or a sticker on the CD, or scratch the surface of the CD.
- After playing, store the CD in its case.

Notes on DualDiscs

- A DualDisc is a two sided disc product which creates DVD recorded material on one side with digital audio material on the other side. However, since the audio material side does not conform to the Compact Disc (CD) standard, playback on this product is not guaranteed.

Music discs encoded with copyright protection technologies

- This product is designed to playback discs that conform to the Compact Disc (CD) standard. Recently, various music discs encoded with various protection technologies are marketed by some record companies. Please be aware that among those discs, there are some that do not conform to the CD standard and may not be playable by this product.

On power sources

- For AC operation, use the supplied AC power cord; do not use any other cord.
- Unplug the unit from the wall outlet if it is not to be used for an extended period of time.
- When not using the batteries, remove them to avoid damage that can be caused by battery leakage or corrosion.

On placement

- Do not leave the unit in a location near heat sources, in a place subject to direct sunlight, excessive dust or mechanical shock, or in a car subject to the direct rays of the sun.
- Do not place the unit on an inclined or unstable surface.
- Do not place anything within 10 mm of the rear of the cabinet. The ventilation openings must be unobstructed for the unit to operate properly and prolong the life of its components.
- Since a strong magnet is used for the speakers, keep personal credit cards using magnetic coding or spring wound watches away from the unit to prevent possible damage from the magnet.

On operation

- If the unit is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens inside the CD player section. Should this occur, the unit will not operate properly. In this case, remove the CD and wait about an hour for the moisture to evaporate.

On handling the unit

- Do not leave the CD compartment open to avoid dust and debris contamination.

On cleaning the cabinet

- Clean the cabinet, panel and controls using a soft cloth slightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder, or solvent, such as alcohol or benzine.

If you have any questions or problems concerning your unit, consult your nearest Sony dealer.

Messages

DATA ERROR: An audio file is corrupted.

ERASE ERROR: Erase of the audio files or folders failed.

FATAL ERROR: The USB device was removed during recording or erase operation, and may have been damaged.

FULL: You tried to program more than 25 tracks or files (steps).

LOW BATTERY: The batteries are almost exhausted.

NO BT: Bluetooth connection is not established.

NO DEV: No USB device is connected or the connected USB device has been removed.

NO STEP: All of the programmed tracks/files have been erased.

NO TRK: There are no playable MP3/WMA files on the USB device.

NO SIGNAL: There is no supported DAB/DAB+ broadcast in your country or region or you have lost the reception of the selected DAB/DAB+ broadcast.

NOT IN USESD: You tried to perform a specific operation under conditions in which that operation is prohibited.

NOT SET: There is no stored preset station.

NOT SUPPORT: An unsupported USB device is connected.

OFF-AIR: The selected station or service is currently not broadcasting.

PROTECT: The connected USB device is write-protected. Remove the USB device, and then clear the write protection, or use another USB device.

PUSH STOP: You tried to perform a specific operation that is prohibited while playing or paused. Press [13] to stop playback, and then try the operation again.

REC ERROR: Recording did not start, stopped partway, or otherwise could not be performed.

Troubleshooting

General

- The power does not turn on when the AC power cord is connected.
- Make sure the AC power cord is connected to the wall outlet securely.

The power does not turn on during battery operation.

- Make sure the batteries are inserted correctly.

"LOW" and "BATTERY" are displayed alternately and the unit turns off automatically.

- Replace all the batteries with new ones.

The unit enters standby mode unexpectedly.

- This is not a malfunction. The unit enters standby mode automatically after about 15 minutes if there is no operation or audio signal output. See "To use the power-management function."

There is no sound.

- Make sure the appropriate function is selected for the music or sound source you want to listen to.
- Unplug the headphones when listening through speakers.

The sound is noisy.

- Is someone using a mobile phone or other equipment emitting radio waves near the unit? If so, move the unit and the Bluetooth device away from such devices. Devices such as mobile phones, etc., can affect Bluetooth communication.

CD/MP3/WMA player

The CD player does not play or "NO DISC" is displayed even when a CD is in place.

- Place the CD with the label side up.
- Clean the CD.
- Take the disc out and leave the CD compartment open for about an hour to dry moisture condensation.
- The CD-R/CD-RW is blank or unfinalized.
- There are no playable MP3/WMA files on the disc.
- There is a problem with the quality of the CD-R/CD-RW, recording device or application software.
- Replace all the batteries with new ones if they are exhausted.

The sound drops out.

- Reduce the volume.
- Clean the CD, or replace it if the CD is badly damaged.
- Place the unit in a location free from vibrations.
- Clean the lens with a commercially available blower.
- The sound may drop out or noise may be heard when using a poor quality CD-R/CD-RW or if there is a problem with the recording device or application software.

Starting playback takes more time than usual.

- The following discs take a longer time to start playback:
 - A disc recorded with a complicated tree structure.
 - A disc that has many folders or non-MP3/WMA files.

USB device

The USB device does not work properly.

- If you connect an incompatible USB device, the following problems may occur:
 - The USB device is not recognized.
 - File or folder names are not displayed on this unit.
 - Playback is not possible.
 - The sound skips.
 - There is noise.
 - The sound output is distorted.

"OVER CURRENT" appears.

- An abnormal level has been detected in the electrical current from the ◁ (USB) port [2]. Turn off the unit and remove the USB device from the ◁ (USB) port [2]. Make sure there is no problem with the USB device. If this message persists, contact your nearest Sony dealer.

There is no sound.

- The USB device may be connected incorrectly. Turn off the unit and reconnect the USB device. Then turn on the unit.

There is noise, skipping, or distorted sound.

- Turn off the unit and reconnect the USB device.
- The music data itself contains noise, or the sound is distorted. Noise may have entered during the creation of audio files. Try re-creating audio files and use them to play on this unit.

The USB device cannot be connected to the ◁ (USB) port [2].

- The connector on the USB device or the USB cable is being inserted backwards. Insert it in the ◁ (USB) port [2] in the correct direction.

"READING" is displayed for an extended time, or it takes a long time before playback starts.

- The reading process can take a long time in the following cases:
 - There are many folders or files on the USB device.
 - The file structure is complex.
 - The memory is almost full.
 - The internal memory is fragmented.

To avoid the above problems, we recommend that you adhere to the following guidelines:

- Keep the total number of folders on a USB device to 100 or less.
- Keep the total number of files per folder to 100 or less.

Erroneous display

- The data stored on the USB device may be corrupted. Send the music data to the USB device again.
- This unit can display only numbers and letters of the alphabet. Other characters will not be displayed correctly.

"REC ERROR" appears.

- An error occurred during recording. Turn off the unit and remove the USB device from the unit. Then check the following:
 - Check the remaining storage space on the USB device. If there is insufficient space for the recording, delete any unnecessary files or folders.
 - Check that the data to be recorded is not corrupted.
 - Check that the file format to be recorded is compatible with the unit.
 - If the message still persists, contact your nearest Sony dealer.

The USB device is not recognized.

- Turn off the unit and reconnect the USB device, then turn on the unit.
- The USB device is not functioning properly. Refer to the USB device operation manual for details on how to deal with this problem.

Play does not start from the first track.

- Set the play mode to Normal Play.

MP3/WMA files cannot be played back.

- The audio files may have inappropriate file extensions. The file extensions supported by this unit are as follows:
 - MP3, file extension "mp3"
 - WMA, file extension ".wma"
- The audio files may have been created in formats other than MP3/WMA formats.
- The USB storage device uses a file system other than FAT16 or FAT32.*
- The USB storage device is partitioned. Only MP3/WMA files in the first partition can be played.
- Playback is possible up to 8 directory levels.
- The number of folders on the device exceeds 255 (including the "ROOT" folder).
- The number of files on the device exceeds 5,000.
- The number of files per folder exceeds 999.
- The files are encrypted or protected by passwords.

* This unit supports FAT16 and FAT32, but some USB storage media may not support both file systems. For details, refer to the operation manual of the USB storage device in question or contact the manufacturer.

Specifications

CD player section
System
Compact disc digital audio system
Laser diode properties
Emission duration: Continuous
Laser output: Less than 44.5 μW
(This output is the value measurement at a distance of 200 mm from the objective lens surface on the optical pick-up block with 7 mm aperture.)

Number of channels
2
Frequency response
20 Hz — 20,000 Hz +1/-2 dB
Wow and flutter
Below measurable limit

Bluetooth section
Communication System
Bluetooth Specification Version 3.0
Output
Bluetooth Specification Power Class 2
Maximum communication range
Line of sight approx. 10 m¹

Frequency band
2.4 GHz band (2,400 GHz — 2,4835 GHz)
Modulation method
Supported Bluetooth Profiles²
A2DP (Advanced Audio Distribution Profile)
AVRCP³ (Audio/Video Remote Control Profile)
Supports codec⁴:
SBC (Subband Codec).

¹ The actual range will vary depending on factors such as obstacles between devices