

Operating Instructions



ICD-TX800


4-699-321-52(1)



(1)

Let's try out your new IC recorder

Charge



① Charge the IC recorder.


Using the supplied USB cable, connect the USB/Headphone connector inside the USB connector cover to a USB port of a running computer. Charging starts. When the battery is fully charged, the battery indicator will indicate .

② Disconnect the IC recorder.

Make sure that the message "Accessing" is no longer on the display window. Then refer to the Help Guide to remove the IC recorder safely.

Power on


IC recorder



Slide and hold the HOLD+POWER switch on the IC recorder in the direction toward "POWER" until the window display appears.

To power off, slide the HOLD+POWER switch on the IC recorder to "POWER" and hold it until "Power Off" appears on the display window.

Remote control



Slide the HOLD switch away from "HOLD". To power on the remote control, press any one of the buttons on the remote control. When the operation indicator on the remote control stops flashing, operations with the remote control are available.

The remote control is not equipped with the power button. It automatically powers off in the following cases:

- If the wireless connection is not established with the IC recorder and you leave the remote control unused for about 5 minutes
- If the wireless connection is established with the IC recorder and - you power off the IC recorder

- you leave the remote control unused for about 2 hours

To use the remote control for operations after it powers off, follow the above procedure to power on the remote control, and then press your desired button on the remote control again.

To prevent unintentional operations (HOLD)

The IC recorder and the remote control are each equipped with the switch to hold the operation.


Slide the HOLD+POWER switch on the IC recorder or the HOLD switch on the remote control in the direction of "HOLD".

IC recorder Remote control



③ To release the IC recorder or the remote control from the Hold status, slide the HOLD+POWER switch towards the center or the HOLD switch away from "HOLD", respectively.

Initial settings



When you power on your IC recorder for the first time, the "Configure Initial Settings" screen appears on the display window of the IC recorder. Use the remote control to make initial settings, such as selecting the display language, setting the clock, and turning on/off the beep sound.

① Slide the HOLD switch away from "HOLD" to release the remote control from the HOLD status.

Remove the yellow label from the back of the remote control when you use it for the first time.

② When "Configure Initial Settings" screen appears, press any button on the remote control.

If the operation indicator on the remote control is flashing, wait until it stops flashing before proceeding to the next step.

③ Select "Delete A File" from the OPTION menu.

④ Press to start the initial settings.

⑤ Press to start the initial settings.

⑥ Select the display language.

You can select from the following languages: Deutsch (German), English, Español (Spanish), Français (French), Italiano (Italian), Русский (Russian), Türkçe (Turkish)

* Default setting

⑦ Set the current year, month, day, hour, and minute.

⑧ Go back to the previous clock setting item, press BACK/HOME.

⑨ Select "Next."

⑩ Select "Yes."

⑪ Select "No."

⑫ Select "Yes."

⑬ Select "No."

⑭ Select "Yes."

⑮ Select "No."

⑯ Select "Yes."

⑰ Select "No."

⑱ Select "Yes."

⑲ Select "No."

⑳ Select "Yes."

⑷ Make sure that you accept the terms of the license agreement, select [I accept the terms in the license agreement], and then click [Next].

* The indicator changes in color or flashes to indicate the status of the Bluetooth function or the Bluetooth pairing (device registration). Sliding the HOLD+POWER switch to "POWER" and holding it for 8 seconds or longer restarts your IC recorder. Before restarting the IC recorder, make sure the operating indicator is off. For detailed instructions, refer to the Help Guide.

* When using the remote control, do not touch the built-in antenna, for example with your hand, so as not to disturb the wireless connection.

* Press this button once to display the previous screen. Press and hold it to display the HOME menu screen.


* There is a tactile dot on the button and next to on the VOL +/- (volume +/-) button.

* Press this button when the remote control seems not working.

* A button type lithium battery is already installed.

* Your IC recorder is not equipped with built-in speakers.

Record



① To start recording, you can operate either the IC recorder or the remote control.

② Before you start recording, make sure that the HOLD status is released.

③ You can select a scene operation for each situation by selecting "Scene Select" in the OPTION menu with the remote control.

④ Turn the IC recorder so that its built-in microphones point in the direction of the recording source.

⑤ Press .

Make sure that the operation indicator on the IC recorder lights in red, indicating that recording has started.

⑥ Press .

Recording stops and "Saving..." appears on the display window.

⑦ Press to stop recording.

Recording stops and "Saving..." appears on the display window.

Listen

Your IC recorder is not equipped with a built-in speaker. For audio listening, you need to connect the stereo headphones (supplied) to the IC recorder with the dedicated headphone cable (supplied). For playback operations, use the remote control.

To power off, slide the HOLD+POWER switch on the IC recorder to "POWER" and hold it until "Power Off" appears on the display window.

Listening preparation

Connect the stereo headphones to the USB/Headphone connector on the IC recorder with the dedicated headphone cable.



Slide the HOLD switch away from "HOLD".

To power on the remote control, press any one of the buttons on the remote control. When the operation indicator on the remote control stops flashing, operations with the remote control are available.

The remote control is not equipped with the power button. It automatically powers off in the following cases:

- If the wireless connection is not established with the IC recorder and you leave the remote control unused for about 5 minutes
- If the wireless connection is established with the IC recorder and - you power off the IC recorder


- you leave the remote control unused for about 2 hours

To use the remote control for operations after it powers off, follow the above procedure to power on the remote control, and then press your desired button on the remote control again.

To operate your IC recorder using a smartphone

You need to install REC Remote on the smartphone and make a pairing between the smartphone and your IC recorder.

Pairing means having Bluetooth devices registered with each other to establish a wireless connection for the first time. To make a pairing with the IC recorder using REC Remote, you need the latest version of REC Remote. If your smartphone has REC Remote already installed, be sure to upgrade it to the latest version.



① While watching the display window on the IC recorder, operate the remote control to select from the HOME menu.

② Select "Latest Recording," "Search by REC Date," "Search by REC Scene," or "Folders."

③ Select your desired file.

④ Press or to adjust the volume.

⑤ Press to stop playback.

⑥ Right after you stopped recording, you can press to play the file you have just recorded.

⑦ To start playback, display the screen for REC Remote on the smartphone.

⑧ On the IC recorder, select "REC Remote" - "Add Device (Pairing)" from the HOME menu with the remote control and follow the on-screen instruction to turn on the Bluetooth function.

⑨ On the smartphone, start REC Remote and select "ICD-TX800" (your IC recorder) from the available device list. For detailed instructions, refer to the help of REC Remote and the manual supplied with the smartphone.

⑩ Now you can use the smartphone for IC recorder operations.

⑪ Note

The device registration (pairing) information is cleared in the following cases. You need to pair the devices once again.

- The settings on the IC recorder, the smartphone, or both devices are reset to the default settings, for example, due to initialization.

- The device registration (pairing) information is deleted, for example, during a repair service.

⑫ To turn on or off the Bluetooth function of your IC recorder


⑬ Follow the instructions in "Charge" to connect your IC recorder to a computer.

⑭ Drag and drop the files or folders you want to copy from "IC RECORDER" to the local disk on the computer.

⑮ Disconnect your IC recorder from the computer.

⑯ Turning off the Bluetooth function conserves battery power.

Initial settings



When you power on your IC recorder for the first time, the "Configure Initial Settings" screen appears on the display window of the IC recorder. Use the remote control to make initial settings, such as selecting the display language, setting the clock, and turning on/off the beep sound.

① Slide the HOLD switch away from "HOLD" to release the remote control from the HOLD status.

Remove the yellow label from the back of the remote control when you use it for the first time.

② When "Configure Initial Settings" screen appears, press any button on the remote control.

If the operation indicator on the remote control is flashing, wait until it stops flashing before proceeding to the next step.

③ Select "Delete A File" from the OPTION menu.

④ Press to start the initial settings.

⑤ Press to start the initial settings.

⑥ Select the display language.

You can select from the following languages: Deutsch (German), English, Español (Spanish), Français (French), Italiano (Italian), Русский (Russian), Türkçe (Turkish)

* Default setting

⑦ Set the current year, month, day, hour, and minute.

⑧ Go back to the previous clock setting item, press BACK/HOME.

⑨ Select "Next."

⑩ Select "Yes."

⑪ Select "No."

⑫ Select "Yes."

⑬ Select "No."

⑭ Select "Yes."

⑮ Select "No."

⑯ Select "Yes."

⑰ Select "No."

⑱ Select "Yes."

⑲ Select "No."

⑳ Select "Yes."

⑴ Make sure that you accept the terms of the license agreement, select [I accept the terms in the license agreement], and then click [Next].

* The indicator changes in color or flashes to indicate the status of the Bluetooth function or the Bluetooth pairing (device registration). Sliding the HOLD+POWER switch to "POWER" and holding it for 8 seconds or longer restarts your IC recorder. Before restarting the IC recorder, make sure the operating indicator is off. For detailed instructions, refer to the Help Guide.

* When using the remote control, do not touch the built-in antenna, for example with your hand, so as not to disturb the wireless connection.

* Press this button once to display the previous screen. Press and hold it to display the HOME menu screen.

* There is a tactile dot on the button and next to on the VOL +/- (volume +/-) button.

* Press this button when the remote control seems not working.

* A button type lithium battery is already installed.

* Your IC recorder is not equipped with built-in speakers.

* The indicator changes in color or flashes to indicate the status of the Bluetooth function or the Bluetooth pairing (device registration). Sliding the HOLD+POWER switch to "POWER" and holding it for 8 seconds or longer restarts your IC recorder. Before restarting the IC recorder, make sure the operating indicator is off. For detailed instructions, refer to the Help Guide.

* When using the remote control, do

Grabadora IC

Manual de instrucciones



ICD-TX800

Consulte la Guía de ayuda

Este es el Manual de instrucciones en el cual se ofrecen instrucciones sobre las operaciones básicas de la grabadora IC.

Consulte la Guía de ayuda cuando quiera conocer más detalles, las operaciones y las posibles soluciones cuando ocurra algún problema.

http://rd1.sony.net/help/icd/t80/h_ce/




Compruebe los elementos suministrados

- Grabadora IC¹⁾
- Mando a distancia¹⁾
- Auriculares estéreo¹⁾
- Cable de auriculares dedicado¹⁾
- Cable USB¹⁾
- Estuche de transporte¹⁾
- Manual de instrucciones (esta hoja)
- Tarjeta de garantía
- Software para aplicación, Sound Organizer 2 (Archivo del instalador almacenado en la memoria incorporada que pude instalarlo en su ordenador.)

* Ya está instalada una pila de litio tipo botón.

Componentes y controles



La grabadora IC tiene una pinza incorporada en su parte posterior. Puede engancharla en algo, como el dobladillo de un bolso.

1) Micrófonos incorporados
2) Indicador de funcionamiento
3) Ventana de visualización
4) Indicador de Bluetooth¹⁾
5) Cubierta del conector USB
6) Conector USB/Auriculares (interior de la cubierta del conector USB)
7) Botón ■STOP
8) Interruptor HOLD+POWER²⁾
9) Botón ■REC (grabación)
10) Botón ▲/DPC (Digital Pitch Control)
11) Antena incorporada³⁾
12) Botón ■STOP
13) Indicador de funcionamiento
14) Interruptor HOLD
15) Botón ■◀ (revisión/retroceso rápido)
16) Botón ■▶/CASA → HOME⁴⁾
17) Botón ▶ (reproducción/entrar)⁵⁾
18) Botón ■REC (grabación)
19) Botón ■▶/búsqueda/avance rápido)
20) Botón OPTION
21) Botón ▶/A-B (repetición A-B)
22) Botón VOL +/-(volumen +/-)⁶⁾
23) Botón T-MARK (marca de pista)
24) Botón RESET⁷⁾
25) Orificio para correa (No se suministra correa con la grabadora IC.)
26) Compartimento de la pila⁸⁾

¹⁾ El indicador cambia de color o parpadea para indicar el estado de la conexión Bluetooth o el emparejamiento (Bluetooth). (registro de dispositivo)

²⁾ Al deslizar el interruptor HOLD+POWER hasta "POWER" y mantenerlo allí durante 8 segundos o más, se reiniciará la grabadora IC. Antes de reiniciar la grabadora IC, asegúrese de que el indicador de funcionamiento esté apagado. Para las instrucciones detalladas, consulte la Guía de ayuda.

³⁾ Cuando coloca el mando a distancia, no cubra la antena incorporada, por el contrario, de lo contrario, la señal de radiofrecuencia no se recibirá.

⁴⁾ Pulse este botón una vez para visualizar la pantalla anterior. Manténgalo pulsado para visualizar la pantalla del menú HOME.

⁵⁾ Hay un punto táctil en el botón ▶ (reproducción/entrar) y al lado de "x" del botón VOL +/- (volumen +/-).


⁶⁾ Pulse este botón cuando parezca que el mando a distancia no funciona.

⁷⁾ Ya está instalada una pila de litio tipo botón.

⁸⁾ La grabadora IC no está equipada con altavoces incorporados.

Vamos a probar la nueva grabadora IC

Carga



① Cargue la grabadora IC.

Utilizando el cable USB suministrado, conecte el conector USB/auriculares del interior de la cubierta del conector USB a un puerto USB de un ordenador en funcionamiento. Se iniciará la carga.

Cuando la batería se haya cargado completamente, el indicador de energía restante de la batería mostrará "Full".

② Desconecte la grabadora IC.

Asegúrese de que en la ventana de visualización ya no esté mostrándose el mensaje "Accessing". A continuación, consulte la Guía de ayuda para extraer la grabadora IC de forma segura.

Conexión de la alimentación


Grabadora IC



Mantenga deslizado el interruptor HOLD+POWER de la grabadora IC en el sentido de "POWER" hasta que aparezca la ventana de visualización.

Para desconectar la alimentación, deslice el interruptor HOLD+POWER de la grabadora IC hasta "POWER" y sujetelo hasta que en la ventana de visualización aparezca "Power Off".

Mando a distancia



③ Para detener la grabación, pulse ■STOP.

La grabación se detendrá y en la ventana de visualización aparecerá "Saving...".

Escucha

Deslice el interruptor HOLD alejándolo de "HOLD".

Para conectar la alimentación del mando a distancia, pulse cualquiera de los botones del mismo. Cuando el indicador de funcionamiento del mando a distancia deje de parpadear, las operaciones con el mismo estarán disponibles.

El mando a distancia no está equipado con botón de alimentación.

Su alimentación se desconectará automáticamente en los casos siguientes:

- Si no se establece la conexión inalámbrica con la grabadora IC y deja el mando a distancia sin utilizar durante unos 5 minutos
- Si la conexión inalámbrica se establece con la grabadora IC y -deja el mando a distancia sin utilizar durante más de 2 horas

Para reactivar el mando a distancia después de que se haya desconectado su alimentación, siga el procedimiento anterior para conectar la alimentación del mando a distancia, y después, vuelva a pulsar el botón deseado del mismo.

Para evitar el funcionamiento no intencional (HOLD)

La grabadora IC y el mando a distancia están equipados con el interruptor para mantener la operación.

Deslice el interruptor HOLD+POWER de la grabadora IC o el interruptor HOLD del mando a distancia en el sentido de "HOLD".

Grabadora IC



④ Observando la ventana de visualización de la grabadora IC, accione el mando a distancia para seleccionar "■ Recorded Files" en el menú HOME.

⑤ Seleccione "Latest Recording", "Search by REC Date", "Search by REC Scene", o "Folders".

⑥ Seleccione el archivo deseado.

La reproducción comienza.

⑦ Pulse VOL + o VOL - para ajustar el volumen.

⑧ Para detener la reproducción, pulse ■STOP.

⑨ Después de detener la grabación, podrá pulsar ▶ para reproducir el archivo que acaba de grabar.

Para añadir una marca de pista

Cuando conecte la alimentación de la grabadora IC por primera vez, en la ventana de visualización aparecerá la pantalla "Configure Initial Settings". Utilice el mando a distancia para realizar ajustes iniciales, como selección del idioma de la pantalla, ajuste del reloj, y activación/desactivación del pitido.

⑩ Deslice el interruptor HOLD alejándolo de "HOLD" para anular el estado HOLD del mando a distancia.

Retire la etiqueta amarilla de la parte posterior del dispositivo a distancia cuando lo utilice por primera vez.

⑪ Cuando aparezca la pantalla "Configure Initial Settings", pulse cualquier otra de los botones del mando a distancia.

Si el indicador de funcionamiento del mando a distancia está parpadeando, espere hasta que deje de parpadear antes de ir al paso siguiente.

⑫ Seleccione "Delete a File" en el menú OPTION.

17/10/2017 00:00

⑬ Pulse ▶ para comenzar los ajustes iniciales.

Press the Button on the Remote Control to Start

⑭ Seleccione el idioma de visualización.

Puede seleccionar entre los idiomas siguientes:

Deutsch (Alemán), English (Inglés), Español, Français (Francés), Italiano (Italiano), Pyccky (Ruso), Türkçe (Turco)

* Ajuste predeterminado

⑮ Ajuste el año, el mes, el día, la hora, y los minutos actuales.

17/10/2017 00:00

⑯ Para volver al elemento anterior de ajuste del reloj, pulse BACK/HOME.

⑰ Seleccione "Next".

10/10/2017 00:00

⑱ Seleccione "Yes".

17/10/2017 00:00

⑲ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00

⑳ Aparecerá "Please Wait" y permanecerá hasta que se haya borrado el archivo seleccionado.

⑳ Seleccione "Yes".

17/10/2017 00:00