

SONY[®]

Model No. RDP-X200iP

©2012 Sony Corporation

Printed in China

http://www.sony.net/

Reference Guide

GB

Personal Audio Docking System

Reference Guide

GB

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

Reference Guide


GB

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product. Applicable accessory: Remote control.

Reference Guide

GB

Reference Guide




VOLUME + (VOL + on the remote control) and ►II buttons have a tactile dot.


Operations

How to handle an iPod

To set an iPod



To remove an iPod



Notes

- An iPod in a case or cover can be set in this unit. However, if the case or cover interferes with the connection, remove the case or cover before setting the iPod on the Dock Connector.
- When placing or removing the iPod, hold it at the same angle as the Dock Connector on the unit. Do not pull the iPod forward too far.
- When placing or removing the iPod, hold the unit securely.
- Do not twist or bend the iPod, as this may result in connector damage.
- Remove the iPod when transporting it; otherwise, a malfunction may result.
- If the iPod does not reach the supporter on the front of the unit, attach the supplied cushion below the supporter.

To turn the unit on/off

Press I/⏻ (On/Standby). The power indicator lights up when the unit is turned on.

Adjusting the volume

Press VOLUME +/- (VOL +/- on the remote).

Tip

- The power indicator flashes three times in green when the sound is set to either maximum or minimum volume.

Operating an iPod on the Dock

- Set the iPod on the Dock Connector. The Dock Connector can be tilted slightly. For details, see "How to handle an iPod."
- Press I/⏻.
- Press **iPod** to activate the function for iPod. The iPod indicator lights up.
- Press ►II. The iPod begins to play back. If the iPod does not start playing back, operate directly on the iPod. You can operate the connected iPod via this unit or the iPod itself.

To	Press
Pause playback	►II To resume play, press again.
Go to the next track	►► (forward) on the remote
Go back to the previous track	◄◄ (backward)* on the remote
Locate a point while listening to the sound	►► (forward) or ◄◄ (backward) on the remote while playing and hold until you find the desired point.
Go back to the previous menu	MENU on the remote
Select a menu item or a track for playback	⬆ (up)/⬇ (down) on the remote
Execute the selected menu item or begin playback	ENTER on the remote

* During playback, this operation returns you to the beginning of the current track. To go back to the previous track, press twice.

Notes

- If a pop-up message appears on the display of the iPod touch, iPhone or iPad, see "About App."
- Some operations may differ or may not be available on some models of iPod.
- If the battery of the iPod is extremely low, charge it for a while before operation.
- Sony cannot accept responsibility in the event that data recorded to an iPod is lost or damaged when using the iPod connected to this unit.
- For details of environmental conditions for operating an iPod, check the website of Apple Inc.

To remove the iPod


For details, see "How to handle an iPod."

To charge an iPod

You can use the unit as a battery charger for an iPod. Charging begins when the iPod is connected to the unit. The charging status appears in the display on the iPod. For details, refer to the user's guide of the iPod.

Operating by wireless music streaming

By using the Bluetooth connection, you can listen to the sound from an iPod or other Bluetooth device with the unit wirelessly.



Pairing

What is pairing?

Bluetooth devices need to be "paired" with each other beforehand. Once Bluetooth devices are paired, there is no need for pairing again, unless pairing information is deleted.


Bluetooth indicator

Status	Bluetooth indicator (blue)
Bluetooth off	Off
Bluetooth on but not connected	Flashes slowly
Pairing mode	Flashes quickly
Connected or communicating	Lights up

To pair with an iPod

Keep the iPod and the unit within 1 meter of each other for this operation.

- Press I/⏻.
- Press **BLUETOOTH** (Ⓡ on the remote) to turn on the Bluetooth function when the Bluetooth indicator is off. The Bluetooth indicator flashes slowly.
- Press and hold **BLUETOOTH** (Ⓡ on the remote). When pairing starts, a double-beep sound will be heard and the Bluetooth indicator will flash quickly. Pairing mode of the unit is activated.



- Perform the pairing procedure on the iPod to detect the unit. Select "Settings → General → Bluetooth" and turn on the Bluetooth function. The Bluetooth indicator lights up.

Example: iPhone 4S



A list of detected devices appears on the display.

The unit is displayed as "RDP-X200iP"

If "RDP-X200iP" is not displayed, repeat from step 3.

- Select "RDP-X200iP" on the display of the iPod while the Bluetooth indicator flashes quickly. When "Connected" appears on the display of the iPod, pairing and connection are complete.

Example: iPhone 4S



Notes

- The operation and display may differ depending on the model of iPod and/or software version. For details, refer to the user's guide of the iPod.
- Pairing mode is canceled after about 5 minutes. If pairing mode is canceled halfway, start over from step 3.
- If pairing is not complete, start over from step 3.
- To pair with another iPod, repeat steps 1 to 5.
- In step 3, if a double-beep sound is not heard or the Bluetooth indicator does not flash quickly, press and hold **BLUETOOTH** (Ⓡ on the remote) again.
- If you turn off the unit or the iPod before the Bluetooth connection is complete, pairing information will not be memorized, and pairing will not be completed.

Notes on pairing with a Bluetooth device other than iPod

- When pairing with a Bluetooth device other than iPod, after step 3, pass code input may be required in your Bluetooth device. In this case, input "0000."
- The operation and display may differ depending on the Bluetooth device and/or software version. For details, refer to the user's guide of the Bluetooth device.

To listen to sound

Keep the iPod and the unit within 10 meters of each other for this operation.

Check the following before operating the unit.

- The Bluetooth function of the iPod is on.
- Pairing of the unit and the iPod is complete. If pairing is not completed, perform pairing again. (See "To pair with an iPod.")

- Press I/⏻.
- Press **BLUETOOTH** (Ⓡ on the remote) to turn on the Bluetooth function.

The last connected iPod will be reconnected automatically when the Bluetooth function is turned on.

- Select your desired music, video, game, etc., to play on the iPod. For details, refer to the user's guide of the iPod.

Tips

- If the last connected iPod does not reconnect automatically, press **BLUETOOTH** (Ⓡ on the remote). If it still does not reconnect, select the model name of this unit from the iPod. (Perform steps 4 to 5 in "To pair with an iPod.")
- To connect an alternative iPod, which has previously been paired with this unit, press **BLUETOOTH** (Ⓡ on the remote) to disconnect the currently connected iPod. Then select the model name of the unit from the alternative iPod you want to connect.
- You can charge the iPod on the dock while listening to music via Bluetooth connection.
- If the volume level is low, adjust the volume of the unit first. If the volume is still too low, adjust the volume of the Bluetooth device.

To finish listening

Terminate the Bluetooth connection by any of the following operations.

- Turn off the unit.
- Turn off the iPod.
- Press **BLUETOOTH** (Ⓡ on the remote), **iPod**, or **AUDIO IN**.
- Operate the iPod to terminate the connection. For details, refer to the user's guide of the iPod.

To clear the list of models already-paired and memorized in the unit

- Press I/⏻.
- Press **BLUETOOTH** (Ⓡ on the remote) to turn on the Bluetooth function.
- Press and hold **BLUETOOTH** and **VOLUME -** on the unit at the same time. The MEGA BASS indicator flashes.

Notes

- You can perform step 3 to clear the list even during Bluetooth connection.
- This operation cannot be performed when the unit is pairing.
- To pair with this unit again, delete the model name of this unit from the iPod and perform pairing again. (See "To pair with an iPod.")

Connecting optional components

You can enjoy the sound from an optional component, such as a portable digital music player, through the speakers of this unit. Be sure to turn off the power of each component before making any connections.

- Firmly connect the line output jack of the portable digital music player (or other component) to the **AUDIO IN** jack on the back of the unit, using a suitable audio connecting cable (not supplied).
- Press I/⏻ to turn on the unit.
- Press **AUDIO IN** to activate the Audio-in function. The Audio-in indicator lights up.
- Turn the connected component on.
- Play the connected component. The sound from the connected component is output from the speakers of this unit.

Notes

- The necessary type of audio connecting cable depends on the optional component. Be sure to use the correct type of cable.
- If the volume level is low, adjust the volume of the unit first. If the volume is still too low, adjust the volume of the connected component.

Other useful functions

Reinforcing the bass sound

Press **MEGA BASS**.

The MEGA BASS indicator lights up. To return to normal sound, press the button again.

About App

A dedicated Dock App for iPod touch/iPhone/iPad available at Apple App Store.

Search for "D-Sappli" and download the free App to find out more about the functions.

Features

- D-Sappli includes various timer functions: Alarm, Music Play Timer and Sleep Timer.
- You can set up to 10 alarms, using songs in iPod or Preset Sound in D-Sappli for the alarm sound. Music Play Timer allows you to play/pause desired music at a desired time. Sleep Timer allows you to specify a time at which to stop music playback. Alarm, Music Play Timer and Sleep Timer work in combination with the power supply of the unit. Alarm, Music Play Timer and Sleep Timer are available only when D-Sappli is activated.
- D-Sappli also includes a clock display enlarge feature.

Notes

- If the App to link with this unit is not downloaded to the iPod touch/iPhone/iPad, a pop-up message prompting you to download D-Sappli may appear repeatedly. Deactivate the App's link function to stop the pop-up message.
- To deactivate the App's link function: Connect the AC adaptor, and then press I/⏻ to turn off the unit. Remove the iPod touch/iPhone/iPad from the Dock Connector. While holding down ►II, also press and hold I/⏻ on the unit for at least 2 seconds. (The power indicator flashes twice when deactivated.)
- To re-activate the App's link function, repeat the above steps. (The power indicator flashes once when activated.)