



Supplied accessories



Notes

- Do not place anything in a way that it may come in contact with the subwoofer on the bottom.
- Place the TV stand at the center of the system so that no part of it protrudes beyond the perimeter of the system.




- Do not place anything on this system that weighs over 30 kg (66 lb 2 1/4 oz). Such an item can damage the system.
- Do not place any metal objects within 5 cm (2 in) to the left of the system when using the BLUETOOTH function. Doing so may cause audio drop.


1 Connecting with a TV

Is there an optical digital jack on your TV?


YES




Optical digital cable (supplied)



NO



HDMI cable (not supplied)



Notes


- When you use an HDMI cable, connect your TV to the HDMI jack with "ARC" printed on it. Otherwise, no sound will be output.
- Make sure that the HDMI cable is firmly inserted.

2 Setting up the remote control



3 Turning on the system

- Turn on the TV.
- Connect the AC power cord (mains lead) of the system.
- Press the I/⏻ (on/standby) button on the remote control of the system. The display lights.




4 Listening to TV sound from the system

When the TV is connected with the optical digital cable

- Press the INPUT button repeatedly to display [OPT]. You will hear TV sound from the system.
- Press the \sphericalangle (volume) button to adjust the volume.

When the TV is connected with the HDMI cable

- Press the INPUT button repeatedly to display [HDMI].
- Press the MENU button to display [AUDIO], then select [TV AU] - [HDMI]. Refer to "Using the setup display" in the Operating Instructions on how to operate the menu. When [HDMI] is set, you will hear TV sound from the system.
- Press the \sphericalangle (volume) button to adjust the volume.



Setup completed! Enjoy!

Please see the supplied Operating Instructions about the BLUETOOTH connection, USB, and other functions.

