



# CD/DVD Player


Startup Guide / Guide de démarrage / Guía de inicio rápido / Guia de Início Rápido /  
Руководство по началу работы / Іске қосу нұсқаулығы

## 1




## 2



1



2




3



I / ⏻ : / on/standby / marche/veille / encendido/en espera / ligado/em espera /  
вкл./ожидание / қосулы/күту

# 3

1



2

