



Quick Start Guide



NWZ-S636F/S638F/S639F/S736F/S738F/S739F

About the Manual

- **Quick Start Guide:** Explains set up, enabling you to import songs, videos and photos to a computer, and to transfer them to the player.
- **Operation Guide (PDF file):** Explains advanced features of the player and offers troubleshooting information.
- **Troubleshooting:** Explains symptoms, causes and remedies when the player has problems.
- **Precautions:** Explains important notes to prevent accidents.

Supplied Accessories

Please check the accessories in the package.

- Headphones (1)
- Earbuds (Size S, L)*¹ (1)
- USB cable (1)
- Attachment (1)
Use when connecting the player to the optional cradle, etc.



- Audio input cable*² (1)
- Plug adaptor for in-flight use (single/dual)*² (1)
- CD-ROM (1)
 - Windows Media Player 11
 - Media Manager for WALKMAN
 - Content Transfer
 - Operation Guide (PDF file)
- Quick Start Guide (this manual) (1)


*¹For details about changing the size of the earbuds, refer to "Supplied Accessories" in the Operation Guide (PDF file).

*²NWZ-S736F/S738F/S739F only

Before Connecting the Player to Your Computer

Make sure that the OS is Windows XP (Service Pack 2 or later) or Windows Vista, (Service Pack 1 or later) and the installed Windows Media Player version on your computer is 10 or 11.

Charging the Battery




The player's battery is recharged while the player is connected to a running computer.



Note

- While the player is connected to a computer, do not turn on, restart, wake up from sleep mode, or shut down the computer. These operations may cause the player to malfunction. Disconnect the player from the computer before performing these operations.

Parts and Controls




1 BACK/HOME button

Press to go up one list screen level, or to return to the previous menu. Press and hold the BACK/HOME button to display the Home menu.

2 5-way button

Press the ►|| button to start playback. Press the ►|| button to confirm after selecting an item with the ▲/▼/◀/▶ button.



3 Headphone jack

Use this jack to connect the headphones. The headphone cord serves as an FM radio antenna. Therefore, when listening to FM radio, extend the cord as much as possible.

4 WM-PORT jack

Use this jack to connect the supplied USB cable, or optional peripheral devices.

5 NOISE CANCELING switch (NWZ-S736F/S738F/S739F only)

By sliding the NOISE CANCELING switch in the direction of the arrow ►, the Noise Canceling function is activated.

6 Display

7 VOL +/- button

8 HOLD switch

9 OPTION/PWR OFF button



Displays the option menu. If you press and hold the OPTION/PWR OFF button, screen turns off and the player enters standby mode. If the standby mode is retained for about a day, the player turns off completely automatically.

10 RESET button

Resets the player when you press the RESET button with a small pin, etc.

About the Home menu

The Home menu appears when you press and hold the BACK/HOME button. The Home menu is the starting point to play audio, search for songs, change settings, etc.



Press and hold the BACK/HOME button to go to the Home menu.

Installing the Operation Guide and Software

You can install the Operation Guide (PDF file) and software from the supplied CD-ROM following the steps below. When installing, you must log on to your computer as an administrator.

1 Insert the supplied CD-ROM into your computer.

The install wizard will start automatically. Follow the on-screen instructions.

2 When the install menu appears, click on the item to install on the left side, and then click the [Install] button on the right lower side of the screen.

Follow the on-screen instructions. To install the Operation Guide (PDF file), select [Operation Guide].

To view the Operation Guide (PDF file)

After installation completes, a PDF icon appears on your desktop. You can view the Operation Guide by clicking the PDF icon. For details about how to use or set player functions, refer to the Operation Guide (PDF file).

Note

- To view the Operation Guide, you need Adobe Reader or Acrobat Reader 5.0. Adobe Reader can be downloaded from the Internet for free.

About the bundled software

Windows Media Player 11

Windows Media Player can import audio data from CDs and transfer data to the player. When you use copyright protected WMA audio files and copyright protected WMV video files, use this software.

Transferable files: Music (MP3, WMA), Video (WMV), Photo (JPEG)

For details on operation, refer to the Help of the software or visit the following website.

<http://www.support.microsoft.com/>

Hint

- Some computers that already have Windows Media Player 10 installed may encounter file limitation (AAC, video files, etc.) that can be transferred by dragging and dropping. If you install Windows Media Player 11 from the supplied CD-ROM, you can solve this problem, then you can transfer by dragging and dropping again. Before installing Windows Media Player 11, make sure to check whether your software or service corresponds to Windows Media Player 11.



Media Manager for WALKMAN

Media Manager for WALKMAN can transfer music, photos or videos from the computer to the player and import audio data from CDs. Media Manager for WALKMAN can also subscribe to RSS feeds and transfer the music and video files that have been downloaded from RSS channels.

For details on operation, refer to the Help of the software. Audio files (AAC) or videos can also be transferred by dragging and dropping using Windows Explorer as well as Media Manager for WALKMAN.

Transferable files: Music (MP3, WMA, AAC*¹, WAV), Photo (JPEG), Video (MPEG-4 Simple Profile, AVC (H.264/AVC) Baseline Profile, WMV*¹⁺²), Podcast (music, video)

*¹ DRM files are not compatible.

*² Some WMV files cannot be played back after transferred by Media Manager for WALKMAN. If you retransfer them using Windows Media Player 11, they may become playable.

Note

- Copyright protected video files, such as DVD movies or recorded digital television programs, are not supported.



Content Transfer

Content Transfer can transfer music, videos or photos from a computer to the player by a simple drag-and-drop operation. You can use Windows Explorer or iTunes* intuitively to drag and drop data to Content Transfer. For details on operation, refer to the Help of the software.

Transferable files: Music (MP3, WMA, AAC*¹, WAV), Photo (JPEG), Video (MPEG-4 Simple Profile, AVC (H.264/AVC) Baseline Profile, WMV*¹⁺²), Podcast (music, video)

*¹ DRM files are not compatible.

*² Some WMV files cannot be played back after transferred by Content Transfer. If you retransfer them using Windows Media Player 11, they may become playable.

Hint

- ATRAC files can be transferred to the player after conversion to MP3 file format. To convert files, download MP3 Conversion Tool from the customer support website referred in "For the latest information."

Getting Data

To enjoy music, photos, videos and podcasts on the player, you need to prepare the data on your computer. To import the data into your computer, use appropriate software.


Transferring Data

You can directly transfer data by dragging and dropping using Windows Explorer on your computer.

You can also transfer data using the bundled software.

Playable data hierarchy has rules. To transfer data properly, see the following illustrations.

Data hierarchy may differ, depending on your computer environment.



Transferable files

Music: MP3, WMA, AAC*, Linear PCM

Video: MPEG-4, AVC (H.264/AVC), WMV

Photo: JPEG

* Copyright protected AAC files cannot be played back.

Precautions

Notice for customers: the following information is only applicable to equipment sold in countries applying EU directives

The manufacturer of this product is Sony Corporation, 1-7-1 Konan, Minato-ku, Tokyo, Japan. The Authorized Representative for EMC and product safety is Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters please refer to the addresses given in separate service or guarantee documents.

Notice for users

- The recorded song is limited to private use only. Use of the song beyond this limit requires permission of the copyright holders.
- Sony is not responsible for incomplete recording/downloading or damaged data due to problems of the player or computer.
- The ability to display the languages on the bundled software will depend on the installed OS on your computer. For better results, please ensure that the installed OS is compatible with the desired language you want to display.
 - We do not guarantee all the languages will be able to be displayed properly on bundled software.
 - User-created characters and some special characters may not be displayed.
- Depending on the types of the text and characters, the text shown on the player may not be displayed properly on device. This is due to:
 - The capacity of the connected player.
 - The player is not functioning normally.
 - Content information is written in the language or the character that is not supported by the player.
- If you do not intend to use the player for over half a year, charge the battery at least once per 6 to 12 months for the battery maintenance.

For the latest information

If you have any questions or issues with this product, or would like information on compatible items with this product, visit the following web sites.

For customers in Canada: <http://www.sony.ca/ElectronicsSupport/>

For customers in Europe: <http://support.sony-europe.com/DNA>

For customers in Latin America: <http://www.sony-latin.com/index.crp>

For customers in other countries/regions: <http://www.sony-asia.com/support>

For customers who purchased the overseas models: <http://www.sony.co.jp/overseas/support/>